Assembly Instructions
Covey Chandelier # PCVY2651

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

1. Attach the nipple(-a) to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Adjust the arms of the fixture according to the drawing of the package.
   Important:
   a. The arms should be positioned with equal distances between them.
   b. The arms should be fixed securely.
4. Attach the two dust-proof meshes onto the socket base by aligning the holes, then secure them with four set screws.
5. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
6. Screw the nipple(-c) into the coupling on the socket base, then secure it with a hex nut.
7. Attach the tube, cap(-a), metal pad, rubber pad and glass shade with the open side facing upward to the coupling, then secure the glass shade with cap(-b) and finial.
8. Thread the fixture wire and the fixture grounding wire through the ball nut and the tube, then secure them with the loop.
9. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain. Then connect one end link of the chain with the loop by using the loop lock.
10. Secure the top loop to the nipple(-a).
11. Thread the fixture wire and the fixture grounding wire through the collar, canopy, top loop, nipple(-a) and mounting strap.
12. Connect the link on the other end of the chain with the top loop by using the loop lock.
13. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
    ---The smooth wire (marked) from the fixture to the black wire from the power source.
    ---The ridged wire (unmarked) from the fixture to the white wire from the power source.
    ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
    Carefully tuck the wires back into the outlet box.
14. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
15. Turn on the power at the main fuse or circuit breaker box.